



Xprinter: Thermal Receipt Printer Installation Guide (Windows Vista 32-bit)

Thank you for purchasing the USBSwiper Thermal Receipt Printer for the Windows Vista 32-bit Operating Systems.

This installation guide will walk you through the necessary steps in order to install this printer properly on your system and use with USBSwiper™ software.

As always, if you have any questions please call our Technical Support Team @ (816)332-6545.

Step One: Unpacking your Xprinter Thermal Receipt Printer

1. Unpack your printer and save the packaging materials.
2. Make sure you have the following items below.
 - Printer
 - Power adapter
 - Power cord
 - USB to DB25 adapter cable


Step Two: Connecting your Xprinter Thermal Receipt Printer

1. Plug the power cord into the power adapter.
2. Plug the power adapter into the printer.
3. Plug the other end into a power outlet.
4. Plug the USB adapter cable into the printer and tighten the screws.
5. Plug the other end of the USB adapter into an available USB port on your computer.


Step Three: Installing the Software

1. Close all running applications.
2. Verify you're running a 32-bit machine and not a 64-bit machine.
 - Go to the Start Menu > Right-click on Computer
 - Next to System type, it will say 32-bit Operating System.
3. Go to www.usbswiper.com/download and click on the 32-bit link next to Xprinter Drivers link.


When asked to Open or Save File, Select Save File and Click OK.




Once the download is complete, open the Zip Folder named printer_driver_x86 from its saved location.




Click on Extract all files to begin the Extraction Wizard.




The Extraction Wizard will guide you through the extraction process.




Once all files have been extracted, double-click on 58DRVEN V6.31 to begin the Setup Wizard.




The Setup Wizard will guide you through installing the Xprinter drivers.




Read the License Agreement. If you agree, select “I accept the agreement” and click Next.




Click Next.




Click Install.




Select Windows Vista and Click Next.



Leave all Detail Settings and Click OK. We will change the printer name and port later.




Click Finish.




Step Four: Change Printer Name and Port

Go to the Start Menu > Control Panel > Printer. Right click on XP-58IIA and go to Properties.




Rename the printer, if you wish.






Select the Ports Tab and the USB001 Virtual Printer Port for USB. Click Apply.
*Do not close the window. You will print a test page next.



Step Five: Test Xprinter Thermal Receipt Printer

From the Properties Window, select the General Tab and Click Print Test Page.



Once the Test Page has printed, you're now ready to print credit card sales receipts from USB Swiper!

If you have any general questions, please email support@usb swiper.com or if you need to schedule a session to complete the installation, please call our Technical Support Team @ (816)332-6545.

Thanks again for choosing USB Swiper!